


#13-172 / #13-176 / #13-191

Bon Gun & Hoppers



Always wear safety glasses when using this unit.

Parts List

Part #	Key #	Detail	Qty/Unit	Part #	Key #	Detail	Qty/Unit
50-710	001	Retaining Ring	1	50-723	014	Control Knob Assembly	1
50-711	002	4mm Nozzle Fluid	1	50-724	015	O-Ring	1
50-712	003	6mm Nozzle Fluid	1	50-725	016	Bushing Nut	1
50-713	004	8mm Nozzle Fluid	1	50-726	017	O-Ring	1
50-714	005	E-ring	1	50-727	018	Repl. Nozzle set	1
50-715	006	Trigger Pin	1	13-111	019	Repair Kit (Complete as above)	1
50-716	007	Gun Trigger	1	50-729		Spray Gun Only	1
50-717	008	Trigger Latch	1	50-734*		Standard Hopper- White	1
50-718	009	Air Inlet Valve	1	50-731*		Touch-Up Hopper - White	1
50-719	010	Hose Connector	1	50-732	023	Brass Elbow	1
50-720	011	Air Stem	1	50-733	024	Rubber Coupler	1
50-721	012	O-Ring x 4	4	50-735	026	90° Plastic Elbow	1
50-722	013	Guide Nut	1				

Order by Part #

** Only one hopper per unit*

Toll Free Order Hotline

800-444-7060

Bon®

Trusted since 1958

4430 Gibsonia Rd. • Gibsonia, PA 15044 • USA • www.bontool.com